

QUICK CHANGE REPLACEMENT POWDER BAR

SUITS ALL DILLON RELOADERS

QUICK CHANGE INSTRUCTIONS



Loosen this screw
1/2 turn.



Wedge out the drive
plate until the square
plastic drive disengages
from the bar.



Withdraw the bar until
the insert clears the
frame. (You will lose
some powder here.)



Replace the insert
with the new load.



Push the bar back in
taking care to align
the square plastic
drive.
Remove the wedge.

The standard Dillon adjustable charge bar works well on larger loads, however small pistol loads do not meter well due to the shape of the cavity. This is particularly noticeable where dense large grain or bulky powders are used. A cylindrical cavity gives a much more consistent powder throw as there are no tight corners where powder can hang up and produce a light charge.

The SRF Quick Change replacement charge bar is supplied with 4 aluminium inserts with pilot holes. The inserts should be drilled with a small hole and gradually opened out with progressively larger drills until the desired load is achieved using your favourite powder.

The use of a drill press is highly recommended.

Once you are satisfied with your load it will always be the same with that insert and powder.

With the 4 inserts included you can have 4 different loads which can be quickly and easily changed with no fiddling of adjustment screws.

EXAMPLE APPROXIMATE SIZES

8.5mm = 2.4gn Trail Boss (approx.)

5.5mm = 2.4gn Bullseye (approx.)

5.5mm = 2.3gn VihtaVouri 310 (approx)

5.5mm = 2.7gn Ap70 (approx)

